

## PROCESSING

Tecoform® compounds can be processed in all commercial injection molding machinery.

### Injection Molding Machine

Selecting the proper design injection molding machine is important to have economic and quality moldings.

As a general rule, capacity of an injection molding machine should have 0.50 – 1.0 tons of clamping force for every square centimeter of projected shot area.

General purpose screw designs with compression ratios between 2.0:1 – 2.5:1, and screw size of 17D to 23D are recommended. Standard nitride screws and barrels are not resistant to the abrasion of fillers, especially glass fibers. However, bi-metallic barrel liners and surface hardened screws show outstanding resistance to wear.

Due to reduced shear general purpose open nozzles that are as short as possible are suggested. The temperature control of the nozzle is very important in order to avoid thermal loss or overheating. In general nozzle diameters should be 3 to 6 mm depending on the size of the part.

It is important to have precise temperature control for processing POM compounds therefore several heating zones of the barrel are necessary.

Cooling system of the feed throat is important to prevent sticking of the granules and to have consistent feed of material to barrel. On the other hand, too low throat temperature will cause condensation, resulting hydrolysis and melt foaming. Temperatures between 30°C – 50°C are suggested.

When molding POM the shot size should be between 20% - 80% of barrel capacity. Shots larger than 80% may generate improper melting, where shots less than 20% will increase the residence time of the material in the machine that can cause degradation, brittleness and discoloration.

Residence time of Tecoform® compounds in the barrel at correct processing temperatures should not exceed 5 minutes.

### Molding Conditions

POM compounds absorb very low amount of moisture and normally pre-drying is not necessary however due to poor storage conditions Tecoform® grades can be dried at 100 - 120°C for 3 – 6 hours.

Some guide recommendations for processing parameters are presented in [Table 1](#).

The temperature of the melt in injection molding depends on barrel temperature settings, material residence time, screw design and speed. As it is difficult to estimate the effect of each parameter on melt temperature, it is suggested to be measured periodically with a pyrometer from the purged molten polymer. Tecoform® compounds should always be molded in a temperature-controlled mold. Uniform mold temperature within the cavity is very important to have good quality parts.

For un-reinforced POM the peripheral screw speed should be maximum 300 mm/s where for reinforced types it should not exceed 200 mm/s in order to minimize fiber breakage, material degradation and discoloring.

Back pressure should be as low as possible to protect material properties.

The actual required injection pressure depends on many variables, such as melt and mold temperatures, part thickness and flow length. It is only necessary to have enough injection pressure to fill the cavity of the mold.

	Grade	Feed Throat Temperature (°C)	Processing Temperature (°C)	Mold Temperature (°C)	Hold Pressure (MPa)
Tecoform® PO (POM)	Un-reinforced	30-50	180 - 220	60 - 100	80 - 100
	Impact Modified	30-50	170 - 210	60 - 80	80 - 100
	Reinforced	30-50	190 - 230	60 - 120	80 - 100

Table 1. Recommended processing parameters for Tecoform®

Due to high crystalline nature of POM, it is required to use fast injection rates especially in reinforced grades. Slow injection rates can be used at the start-up of the injection to prevent jetting and burning of material.

The mold shrinkage of POM mostly depends on the holding pressure and the holding time. During this stage material melt is continuously pushed into the part cavity which compensates the shrinkage of the part during solidification. The level of holding pressures and time that depend mainly on the part thickness and runner geometry are generally 1:2 to 2:3 of the maximum injection pressure. For processing very precise parts, injection and hold pressure can be set to be equal.

Effects of main processing parameters on material properties are shown in Table 2.

Processing Parameter	Weld Line Strength	Surface Quality	Cycle Time	Shrinkage	Sink Mark
Melt Temperature ↗	↗	↗	↗		
Mold Temperature ↗	↗	↗	↗	↗	
Hold Pressure ↗				↘	↘
Injection Speed ↗	↗	↗			

Table 2. Effect of processing parameters on material properties

## Recycling

Regrind levels up to 20% can be reused depending on the application and requirements. Regrinds should be free of contamination, should not be thermally degraded and must be dried prior to reuse.